




AUSTEC IRRIGATION

www.austecnt.com.au



POP SPRINKLER KEEPS LEAKING

Many people believe a leaking sprinkler is faulty and requires replacement. This is very rarely the case.

Water will leak out of the lowest pop up sprinkler on a line for some time after a valve has closed. This can be corrected by installing a check valve in the base of the pop up sprinkler.

However, if water continually leaks out of the lowest pop up sprinkler, it is because the solenoid valve is leaking and needs to be repaired – not the pop up sprinkler.

**WHY GO TO A HARDWARE STORE...
WHEN YOU CAN GO TO AN AUSTEC STORE!**